




WINDOWS 7

1. Go to **Start Menu ► Control Panel ► Hardware and Sound ► Sound**.
2. Select the **"Recording"** tab.
3. Make sure **Microphone – USB Audio CODEC** is set as the default device, then click **"OK."**



MAC

1. Go to **Applications ► Utilities ► Audio MIDI Setup**.
2. Under the list of audio devices, select **USB Audio CODEC – 2 in / 0 out**.
3. Click the gear icon at the bottom-left corner of the window and select **"Use this device for sound input."**
4. When the microphone icon appears to the right of **USB Audio CODEC – 2 in / 0 out**, close the window.



SOFTWARE

You can use PhonoLink with any digital audio workstation or recording software that supports USB audio devices. You can also download EZ Vinyl/Tape Converter (PC) or EZ Audio Converter (Mac) for free at <http://www.alesis.com/phonolink>. These software applications are easy to use and can get you started quickly, especially if you want to transfer your vinyl recordings onto your computer.